



Tolleranza di serraggio / tolerance on torque value
General: 0 /-20% (*) : 0/-10%

	KIT 111	KIT 345	KIT 346	KIT 348	KIT 350	KIT 351
DENOMINAZIONE - DESCRIPTION	ANELLI RADIALI GUIDE PLUNGER RODS SEALS	VALVOLE A/M + OR CHECK VALVES + O-RING	GUARNIZIONI PACKINGS	GUARNIZIONI+LANTERNE PACKINGS+GLANDS	TAPPI VALVOLA + OR VALVE CAPS + O-RING	TENUTE OLIO OIL SEALS
CODICE - CODE	53.9817.97.3	53.9830.97.3	53.9831.97.3	53.9833.97.3	53.9835.97.3	53.9836.97.3
COMPONENTI - COMPONENTS	■	▲	●	▼	◆	■
N° PZ - N° PCS	3	18	18	24	12	12