



Tolleranza di serraggio / tolerance on torque value
General: 0 /-20% (*) : 0/-10%

	KIT 37	KIT 100	KIT 315	KIT 317	KIT 149	KIT 416
DENOMINAZIONE - DESCRIPTION	ANELLI RADIALI GUIDE PLUNGER RODS SEALS	TAPPI VALVOLA + OR VALVE CAPS + O-RING	GUARNIZIONI PACKINGS	GUARNIZIONI+LANTERNE PACKINGS+GLANDS	VALVOLE A/M + OR CHECK VALVES + O-RING	TENUTE OLIO OIL SEALS
CODICE - CODE	06.9814.97.3	06.9844.97.3	06.9968.97.3	06.9970.97.3	08.9819.97.3	06.9991.97.3
COMPONENTI - COMPONENTS	■	▲	●	▼	□	Δ
N° PZ - N° PCS	3	12	18	24	12	9