




Tolleranza di serraggio / tolerance on torque value
General: 0 /-20% (*) 0/-10%

	KIT 64	KIT 124	KIT 73	KIT 68	KIT 67	KIT 79
DENOMINAZIONE - DESCRIPTION	ANELLI RADIALI GUIDE PLUNGER RODS SEALS	VALVOLE A/M + OR CHECK VALVES + O-RING	GUARNIZIONI PACKINGS	GUARNIZIONI+LANTERNE PACKINGS+GLANDS	TAPPI VALVOLA + OR VALVE CAPS + O-RING	TENUTE OLIO OIL SEALS
CODICE - CODE	04.9836.97.3	04.9890.97.3	04.9843.97.3	04.9840.97.3	04.9839.97.3	04.9842.97.3
COMPONENTI - COMPONENTS	■	▲	▼	●	◆	▣
N° PZ- N° PCS	3	12	15	21	12	8